BATTERY.—U. S. L., Type 3HVX-8X, 6 volt. The starting capacity is 170 amperes for 20 minutes. The lighting capacity is 5 amperes for 33 hours. The negative (—) terminal is grounded.

IGNITION:—Coil Model 4035. Distributor Model IG-4036B. Breaker contacts separate .018 inch contacts fully separated. If condition affects ignition, remove and resurface on a hard oilstone.

Oiling.—Put 4 or 5 drops of light engine oil into timer distributor each week. If the car is driven over 250 miles in a week, this care must be given every 250 miles.

Timing.—Breaker contacts just open when flywheel is 12° late on compression stroke, spark control lever and breaker assembly fully retarded.

Firing Order.—The firing order is 1, 3, 4, 2.

Spark Plugs.—Spark plugs, diameter 1/8 inch. Gap, .025 inch.

STARTER:-Model MH-4002. Direction of rotation looking at commutator end is counterclockwise. The starter is connected to engine by a Bendix drive. Motor running free at 4000 R.P.M., takes 40-60 amperes, at 6 volts, cranking engine at 100 to 200 R.P.M., takes 250-300 amperes at 5 volts. Lock torque is 17.5 pound feet, current being 600 amperes at 3-4 volts.

Oiling.—Pour 7 or 8 drops of light engine oil into starter oiler every two weeks. If car is driven over 500 miles in two weeks, this attention must be given every 500 miles.

Keep drive end bearing well lubricated

GENERATOR:-Model GJ-4010A. The direction of rotation looking at commutator end is counter-clockwise. The third brush system is used for voltage regulation. Move third brush in counter-clockwise direction to increase the output, and to decrease, in the opposite direction. The maximum charging rate is 12-13 amperes (generator hot) reached at 1700 R.P.M. of the generator armature or approximately 20-25 M. P. H.

Generator Test Data Cold Test. (77°F.) Hot Test. (167°F.) Volts. Volts. Amperes R.P.M. Amperes. R.P.M. 0 6.8 500 4580740650 8950 152400 11.6 8.12400

Oiling—Pour 7 or 8 drops of light engine oil into generator oiler once a week. If car is driven more than 250 miles in a week, this care must be given each 250 miles.

RELAY.—Relay closes at 7-9 M.P.H., 500-550 R.P.M., 7-8 volts, and opens at 5-7 M.P.H. 450-500 R.P.M., 1-2 ampere discharge. Contacts separate .025-.035 inch; and air gap between relay armature and coil core is .010-.015 inch, contacts closed.

LIGHTING.—Clum Combination Ignition and Lighting Switch is used. Head lamps are 6-8 volts, 21 cp., S.C. Dimmer resistance employed. Tail and dash lamps are 3-4 volts, 2 cp., S.C.

FUSES .- Fuses are 20 amperes.

WILLYS-KNIGHT

MODEL 64-67 (1923-24-25)
AUTO LITE GENERATING, STARTING AND LIGHTING SYSTEM
AUTO-LITE IGNITION

